

## PC/TV Configuration to connect to a TV

These instructions assume the PC has already been properly connected to your TV with the appropriate cabling by an Educational Technology Department Representative.

On your pc:

Right click an open area of your desktop and click Properties

Click on the Settings Tab

Under Screen Resolution, click and drag the slider to 800 x 600 pixels

Click the Advanced button to open the Monitor Properties

Click on the Monitor tab

Under Monitor settings, click the drop down arrow for the Screen refresh rate

Choose 60 Hertz

Click OK

Click OK

On your TV remote:

Click the Input/Source button (depends on model of TV) repeatedly until the image on the pc monitor appears on the TV